




"CABLE TESTER"

USER MANUAL

DNR

"CABLE TESTER"
SERVICE MANUAL

DNR



CABLE UNDER TEST

XLR-FEMALE

CINCH

JACK

SL

1

2

3

PRL-A

D1

D2

9V

R1

R2

JACK

1

2

1

2

CINCH

XLR-MALE

1

2

3

PRL-B